



## 1. How to install LP-II PC Application


Insert the LP-II program installation CD into the CD ROM drive of PC. Installation Wizard starts automatically as below. If the Installation Wizard doesn't start automatically, follow these steps. Open the My Computer folder on the screen of PC, and then open the CD ROM drive. Click "Autorun.exe", Installation Wizard will start.




At first, click "Next" button. You will see the DAO Installation Wizard screen as below. Then, click "Install DAO" button to install DAO on PC.




After installing DAO, click “Next” button to install LP-II PC program. You will see the PC Application Installation Wizard screen as below. Select the version which you want to install, and click “Install Program” button to start the installation of PC program.



After finishing the installation completely, select “Yes, I want to restart my computer now.” Then click “Finish” button. PC restarts, and LP-II PC program installation is completed.




To find LP- II Application program, click Start → Program as below. Messenger is registered as the Tray icon.



When you want to know whether PC is connected with scale or not, click the messenger icon of Tray. When you want to manage PLU registration, start Manager. (Refer to the pages which are explaining about Manager and Messenger of manual for details)

Restart PC, you will see the screen as below. You can set the environments for operation of PC application. Set Communication, Login information, and Manager Options on this screen and click OK button. Messenger starts automatically by network types. This screen is showed only one time when you install the program firstly.



## 2. How to eliminate PC Program (LP-II Manager)

Open Control Panel, and click Program Addition/Deletion button. Choose "LP-II

Manager” and click “Addition/Deletion” button. Now PC program is eliminated.